

# FAT - Vacuum Gripper Robot

## Test items:

### When in resetting State

- 1 all the xyzMovement equipment is resetted, the state idle is activated when the equipment is succesfully initialized

### When in execute State

- 2 The robot moves to the eRemovePos position
- 3 The robot activates the vacuum head
- 4 The robot moves to the ePlacingPos position
- 5 The robot deactivates the vacuum head
- 6 The vertical and horizontal movements return to home pos

### ParamCheck

- 7 If the current state is idle and the CntrCmd == **START**, the next state is not activated if the params aren't OK

### Errors

- 8 The horizontal CNT value hasn't changed while the motor is busy
- 9 The vertical CNT value hasn't changed while the motor is busy
- 10 The rotate CNT value hasn't changed while the motor is busy

**Test #1**    *all the xyzMovement equipment is resetted, the state idle is activated when the equipment is succesfully initialized*

Pre-conditions

1. The current active step is resetting

Test steps

1. None

Expected result

All the Equipment modules are resetted. When:  
*EM\_xyzTransport*  
Are succesfully initialized the next state (idle) is activated.

**Test #2**    *The robot moves to the eRemovePos position*

Pre-conditions

1. The current active step is Idle
2. Valid placing and remove position is set

Test steps

1. Set CntrlCmd to **START**

Expected result

The xyzRobot moves to the eRemovePos in the following steps:  
rotating to correct position, horizontal extending to correct position, vertical lowering to correct position

### Test #3     *The robot activates the vacuum head*

#### Pre-conditions

1. Test #2 has been concluded succesfully

#### Test steps

-

#### Expected result

The vacuumhead is at the correct position. The vacuum is activated essentially picking up the piece.

### Test #4     *The robot moves to the ePlacingPos position*

#### Pre-conditions

1. Test #3 has been concluded succesfully

#### Test steps

-

#### Expected result

The xyzRobot is still at the eRemovePos location. The movement to the placing pos goes as follows:  
Horizontal movement raises to home pos, vertical movement retract to home pos, rotating to correct position, horizontal extending to correct position, vertical lowering to correct position

## Test #5 *The robot deactivates the vacuum head*

### Pre-conditions

1. Test #4 has been concluded succesfully

### Test steps

-

### Expected result

The vacuumhead is at the correct placing position. The vacuum is deactivated essentially freeing the piece.

## Test #6 *The vertical and horizontal movements return to home pos*

### Pre-conditions

1. Test #5 has been concluded succesfully

### Test steps

-

### Expected result

The xyzRobot is still at the ePlacePos location. The vacuum head needs to go to the homepos. The movement goes as follows:

Vertical movement raising to homepos, horizontal movement retracting to home. The rotating movement doesn't need to go to the home position

**Test #7** *If the current state is idle and the CntrCmd == START, the next state is not activated if the params aren't OK*

Pre-conditions

1. The current active step is Idle

Test steps

1. Set CntrlCmd to START

Expected result

The unit should only start when:

eRemovePiece != ePlacePos, eRemovePos != 536632 station, ePlacePos != 536633 station

**Test #8** *The horizontal CNT value hasn't changed while the motor is busy*

Pre-conditions

1. The current active step is Execute
2. Power is removed from CNT signal horizontal motor:



Test steps

-


Expected result

The horizontal motor moves, however the CNT value cannot change, causing an error.

**Test #7**    *The vertical CNT value hasn't changed while the motor is busy*

Pre-conditions

1. The current active step is Execute
2. Power is removed from vertical motor:



Test steps

-


Expected result

The vertical motor won't move, and thus the CNT value cannot change, causing an error.

**Test #8**    *The rotate CNT value hasn't changed while the motor is busy*

Pre-conditions

1. The current active step is Execute
2. Power is removed from rotate motor:



Test steps

-

Expected result

The rotate motor won't move, and thus the CNT value cannot change, causing an error.